

- 1 Introduction
- 2 Dimensions and typical control circuit
- 3 Typical applications
- 4 Terminal specification and block diagram
- 5 Installation and commissioning
- 6 Customer presets and log
- 7 Trouble shooting guide
- 8 Detailed specification

## Introduction. Models 400, 800, 1200

**SPRINT** offers a family of D.C. THYRISTOR drive modules all with the same features and terminals. The user selects the appropriate model depending on required power output. The drives are all NON-ISOLATED.

DRIVE TYPE	AC SUPPLY VOLTAGE	NOMINAL OUTPUT	MAX. CURRENT	NOMINAL POWER
400L/V	30/60	24/48V	4 AMPS	200 W
400	110/240	90/180V	4 AMPS	0.55 KW
800L/V	30/60	24/48V	8 AMPS	400 W
800	110/240	90/180V	8 AMPS	1.2 KW
1200L/V	30/60	24/48V	12 AMPS	600 W
1200	110/240	90/180	12 AMPS	2.0 KW

All types are of open chassis construction. Enclosed versions available as follows. 400E, 400ER, 800E, 800ER, 1200E, 1200ER. E=enclosed, R=reversing

## GENERAL DESCRIPTION

The units employ closed loop control of both armature current and feedback voltage to give precise control of the motor torque and speed. The motor and drive are protected by a stall timer which automatically removes power after 30 seconds if the required speed cannot be achieved. The drives will provide up to 150% of the preset maximum current for up to 30 seconds allowing high short term torques during acceleration etc. Independent control of either the current or speed loops by external inputs allows torque or speed control applications with overspeed or overcurrent protection. The demand signal may be derived from a potentiometer, 0-10V signal or 4-20mA loop. The speed feedback signal may be selected to be the ARMATURE VOLTAGE or a shaft mounted TACHOMETER.



## INPUTS AND OUTPUTS

INPUTS	OUTPUTS
+aux input	speed output
-aux input	current output
current input	ramp output
4-20mA input	stall relay driver
0 to 10V input	zero speed driver
<b>ADJUSTABLE PARAMETERS</b>	Max speed
	Min speed
<b>SWITCHED FUNCTIONS</b>	Maximum feedback
	Torque control
<b>JUMPER FUNCTIONS</b>	Dual supply voltage
	4-20mA input
<b>PERFORMANCE FEATURES</b>	Dual loop control
	Relay driver o/p's
	Precision tachometer
	International compatibility
	Compact design
	Integral fusing

## TYPICAL APPLICATIONS


### TORQUE CONTROL WITH OVERSPEED LIMITING BY SEPERATE SPEED SETPOINT.

If the speed exceeds the level programmed by the speed setpoint, then the current demand comes out of limit and the speed loop takes control.




HEALTH AND SAFETY AT WORK. ELECTRICAL DEVICES CAN CONSTITUTE A SAFETY HAZARD. IT IS THE RESPONSIBILITY OF THE USER TO ENSURE THE COMPLIANCE OF THE INSTALLATION WITH ANY ACTS OR BYLAWS IN FORCE. ONLY SKILLED PERSONNEL SHOULD INSTALL THIS EQUIPMENT AFTER READING THIS MANUAL.

## MECHANICAL DIMENSIONS




- 1 a) The speed setpoint is ramped. The ramp is reset by RUN input.
- 2 a) The output from the SPEED ERROR AMP is current demand. If it remains above 100% for 30 sec, the drive stops, STALL lamp on.
- 3 a) Do not open circuit the field unless it is provided with a separate flywheel diode



- 4 a) The user setpoint pot has +10V from T1 on the CW end, the acw end is set by the MIN SPEED.
- 5 a) The RUN input on T5 must be closed to COM (T4, T7) for the drive to RUN.

## Block diagram and terminal specification.



- 1 +10V PRECISION REFERENCE 10mA MAX. SHORT C.T. PROOF
- 2 MINIMUM END OF SETPOINT POT OR 4-20 mA CURRENT LOOP I/P
- 3 SPEED DEMAND INPUT 0-10V FOR 0-100% SPEED
- 4 COMMON. (4-20mA RETURN)
- 5 CONNECT TO COMMON TO RUN 60ms ON / 20ms OFF
- 6 TACHO INPUT 12-200V FULL SCALE. + OR - POLARITY
- 7 COMMON
- 8 A1+ ARMATURE OUTPUT
- 9 A2- ARMATURE OUTPUT
- 10 F2- FIELD OUTPUT
- 11 F1+ FIELD OUTPUT
- 12 N NEUTRAL AC SUPPLY I/P
- 13 L LINE AC SUPPLY INPUT