



ALL FUSES ARE 3.15 AMP

- ⊙ = TERMINALS ON MAIN PANEL
- NUMBERS IN BRACKETS REFER TO RELAY CONNECTIONS
- » REFERS TO PIN NOS ON PLUG AND SOCKET ASSEMBLY

STARMILL PC  
MAIN POWER  
SCHEMATIC

SHEET No 1

OF

DENFORD MACHINE TOOLS LTD

BRIGHOUSE

WEST YORKSHIRE

DRN BY A McHENRY

DATE

10-01-91

A3-

400201 A