



ALL FUSES ARE 3.15 AMP


⊙ = TERMINALS ON MAIN PANEL

NUMBERS IN BRACKETS REFER TO RELAY CONNECTIONS

» REFERS TO PIN NOS ON PLUG AND SOCKET ASSEMBLY







DENFORD MACHINE TOOLS LTD BRIGHOUSE WEST YORKSHIRE

DRN BY A McHENRY

DATE 14-01-91

A3-400204

STARVILL BC
INPUT & OUTPUT
CONNECTIONS

SHEET No 4

STARVILL SPINDLE DRIVE
CONNECTIONS

