



ESR EMERGENCY STOP RELAY
 < 42 WAY CONNECTOR
 SEE SHEET 4




QM1 = 8 WAY ROUND QM
 CONNECTOR FOR
 AUXILIARIES

REMOTE E-STOP 0v (A) 62 (E) 110 OUTPUT 1
 INPUT 1 (C) 100 (F) 111 OUTPUT 2
 INPUT 2 (D) 101 (G) 68 REMOTE E-STOP
 (H) EARTH



0.5mm BLUE
 0.5mm EARTH

BEAD CAPACITOR
 RS 264-5015

NOTE: E-STOP MONITOR WIRING
 USES SINGLE CORE FROM
 2 CORE SCREEN CABLES



SEE SHEET 1
 FOR POWER SCHEMATIC



NOVATURN EMERGENCY STOP CIRCUIT	SHEET 9
	NOVATURN
	DENSTEP