


1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24

IF IN DOUBT ASK

RS 232  
CHANGE OVER  
KEYSWITCH



CHECK THAT SWITCH  
HAS LINKS FITTED

PINS  
2 - 6  
4 - 8  
10 - 14  
12 - 16